



CMi4140  
User's Manual  
English  
v1.3

## CONTENTS

<b>1</b>	<b>DOCUMENT NOTES .....</b>	<b>3</b>
1.1	COPYRIGHT AND TRADEMARK .....	3
1.2	CONTACTS.....	3
<b>2</b>	<b>IMPORTANT USAGE AND SAFETY INFORMATION .....</b>	<b>4</b>
<b>3</b>	<b>USING THIS MANUAL .....</b>	<b>5</b>
3.1	PURPOSE AND AUDIENCE .....	5
3.2	ONLINE RESOURCES .....	5
3.3	SYMBOLS.....	5
<b>4</b>	<b>INTRODUCTION.....</b>	<b>6</b>
4.1	PURPOSE.....	6
4.2	APPLICATION DESCRIPTION.....	6
4.3	PRODUCT FEATURES.....	6
4.4	COMPATIBILITY.....	6
<b>5</b>	<b>GETTING STARTED.....</b>	<b>7</b>
5.1	PURPOSE.....	7
5.2	PRODUCT SPECIFICATION .....	7
5.3	MOUNT AND START-UP THE DEVICE.....	7
5.3.1	<i>Mounting and connection .....</i>	<i>7</i>
5.3.2	<i>Connection of antenna .....</i>	<i>7</i>
5.3.3	<i>Network preparation .....</i>	<i>7</i>
5.3.4	<i>Activation.....</i>	<i>8</i>
<b>6</b>	<b>ADMINISTRATION REFERENCE.....</b>	<b>10</b>
6.1	PURPOSE.....	10
6.2	SECURITY AND ACCESS CONTROL .....	10
6.3	CONFIGURATION OPTIONS .....	10
6.4	TIME HANDLING .....	11
6.5	ADAPTIVE DATA RATE (ADR) .....	12
6.6	TRANSMIT INTERVAL.....	12
6.6.1	<i>EcoMode .....</i>	<i>12</i>
6.7	MESSAGE FORMATS .....	12
6.7.1	<i>Message structure.....</i>	<i>13</i>
6.7.2	<i>Structure and payload.....</i>	<i>14</i>
6.7.3	<i>Meter communication error message.....</i>	<i>25</i>
6.8	DOWNLINK .....	26
<b>7</b>	<b>TECHNICAL SPECIFICATIONS.....</b>	<b>28</b>
<b>8</b>	<b>TYPE APPROVALS.....</b>	<b>29</b>
<b>9</b>	<b>DOCUMENT HISTORY .....</b>	<b>30</b>
9.1	VERSIONS.....	30
<b>10</b>	<b>REFERENCES.....</b>	<b>31</b>
10.1	TERMS AND ABBREVIATIONS .....	31
10.2	NUMBER REPRESENTATION .....	31
10.3	EUROPEAN STANDARDS .....	31

# 1 Document notes

All information in this manual, including product data, diagrams, charts, etc. represents information on products at the time of publication, and is subject to change without prior notice due to product improvements or other reasons. It is recommended that customers contact Elvaco AB for the latest product information before purchasing a CMi Series product.

The documentation and product are provided on an "as is" basis only and may contain deficiencies or inadequacies. Elvaco AB takes no responsibility for damages, liabilities or other losses by using this product.

## 1.1 Copyright and trademark

© 2021, Elvaco AB. All rights reserved. No part of the contents of this manual may be transmitted or reproduced in any form by any means without the written permission of Elvaco AB. Printed in Sweden.

CMi Series is a trademark of Elvaco AB, Sweden.

## 1.2 Contacts

Elvaco AB Headquarter  
Kabelgatan 2T  
434 37 Kungsbacka  
SWEDEN  
Phone: +46 300 30250  
E-Mail: [info@elvaco.com](mailto:info@elvaco.com)

Elvaco AB Technical Support  
Phone: +46 300 434300  
E-Mail: [support@elvaco.se](mailto:support@elvaco.se)

Online: <http://www.elvaco.com>

## 2 Important usage and safety information

The following safety precautions must be observed during all phases of the operation, usage, service or repair of any CMi Series product. Users of the product are advised to convey the information to users and operating personnel and to incorporate these guidelines into all manuals supplied with the product. Failure to comply with these precautions violates safety standards of design, manufacture and intended use of the product. Elvaco AB assumes no liability for customer's failure to comply with these precautions.

CMi4140 receives and transmits radio frequency energy while switched on. Remember that interference can occur if the product is used close to TV sets, radios, computers or inadequately shielded equipment. Follow any special regulations and always switch off the product wherever forbidden, or when you suspect that it may cause interference or danger.

## 3 Using this manual

### 3.1 Purpose and audience

This manual provides all information needed to mount, deploy and configure CMi4140 and targets installers and system integrators.

### 3.2 Online resources

To download the latest version of this user's manual, or to find information in other languages, please visit <http://www.elvaco.com/>.

### 3.3 Symbols

The following symbols are used throughout the manual to emphasize important information and useful tips:



The Note symbol is used to mark information that is important to take into consideration for safety reasons or to assure correct operation of the meter connectivity module.



The Tip symbol is used to mark information intended to help you get the most out of your product. It might for example be used to highlight a possible customization option related to the current section.

Table 1 provides information on how the product should be used.



Symbol	Description
	Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Contact your Local Authority for recycling advise.
	Electrostatic-sensitive device. Please observe the necessary ESD protective measures when installing the module.

Table 1: Usage information

## 4 Introduction

### 4.1 Purpose

This chapter provides a general description of CMi4140. In the next-coming sections you will learn more about possible applications for the product and how CMi4140 can be combined with other products to build versatile solutions.

### 4.2 Application description

CMi4140 is a cost-effective meter connectivity module, which is mounted in a Kamstrup MULTICAL® 403, MULTICAL® 603 or MULTICAL® 803 heat/cooling meter. It uses a very energy-efficient scheme to deliver meter data to a receiving (application) server over a LoRaWAN network. Meter data is securely transmitted, using LoRaWAN end-to-end security scheme. CMi4140 can be retrofitted into already deployed meters or mounted in the meter before deployment.

### 4.3 Product features

CMi4140 offers a combination of battery operation with very long lifetime and a versatile application through its many configuration options. Key features of the module include:

- **Extensive battery lifetime**  
The module's EcoMode feature enables the module to achieve a battery-lifetime of at least 11+1 years.
- **No meter installation needed**  
As soon as the meter connectivity module is mounted in the meter and activated, it will join the LoRaWAN network and start to deliver meter data, i.e. no manual steps need to be taken in order to install the product in the meter.
- **Easy and secure commissioning**  
With Elvaco's One-Touch Commissioning (OTC), deployment, configuration and key transferring can be performed in a secure and flexible way. Use the Elvaco OTC App to enter your desired settings and place your phone next to the meter. New settings will be applied via NFC.
- **A unique and flexible message scheme**  
CMi4140 has several different message formats to choose from. This makes it easy to customize the product to the unique demands of each application.

### 4.4 Compatibility


CMi4140 is compatible with Kamstrup MULTICAL® 403, MULTICAL® 603 and MULTICAL® 803 heat/cooling meters.

## 5 Getting started

### 5.1 Purpose

This chapter provides instructions on how to get started with the CMi4140. After reading and carefully following each step of this chapter, your meter connectivity module should be mounted and connected to the LoRaWAN network.

### 5.2 Product specification



1. Pulse inputs
2. Power connector
3. Antenna connector

### 5.3 Mount and start-up the device

#### 5.3.1 Mounting and connection

CMi4140 is mounted in the module slot of a Kamstrup MULTICAL® 403, MULTICAL® 603 or MULTICAL® 803 heat/cooling meter. Grab the device by the outer edges, gently press it into position and connect the power connector to the meter power supply.

#### 5.3.2 Connection of antenna

CMi4140 is available in two different versions, with internal PCB antenna (CMi4140Int) and with external antenna (CMi4140Ext), both are connected using an MCX connector.



If using an external antenna, make sure to mount it at least 0.5 meters away from the meter in order not to cause interference.

#### 5.3.3 Network preparation

For the module to connect to the LoRaWAN network, it needs to be added in the network server. More specifically, the following device information needs to be registered: Device EUI, Application key and Join EUI. (If using ABP mode, the following information should be registered instead: Application Session key, Network Session key and Device address.)



Elvaco strongly recommends using Over-the-air activation (OTAA) to facilitate deployment and minimize the risk of duplicated keys.

### 5.3.4 Activation

#### Module activation

Upon delivery, CMi4140 is set to passive mode, which means no messages will be transmitted from the module. The module can be activated in one of the following ways:

- a) **By using the meter front buttons.**
  - On MULTICAL® 403: press and hold both buttons on the front of the meter until "CALL" is displayed.
  - On MULTICAL® 603 and MULTICAL® 803: Press down the two arrow buttons on the front of the meter until "CALL" is displayed.
- b) **By using the Elvaco OTC App.**
  - Open the Elvaco OTC app (downloadable via Google Play) and scan the module (make sure NFC is activated on the phone). Remove the front enclosure of the meter if needed.
  - Go to **Apply mode**, set the Power mode to "active" and click **Apply settings**. Place the phone next to the module. New settings are applied via NFC. You can make sure that the module has joined the LoRaWAN network correctly by checking the "network join" field in the Inspect tab of the OTC App.

#### Network join

When activated, CMi4140 will attempt to join the LoRaWAN network. If the module fails to join the LoRaWAN network it will perform retries until it succeeds. The time between each attempt will increase for every attempt until it's performed once every day. A new join attempt cycle can be manually started anytime by deactivating and activating the module using the Elvaco OTC App.

When the module has joined the LoRaWAN network, meter data will initially be transmitted from the module every minute (regardless of transmit interval settings) in order to set the right data rate. After three minutes of calibration, the module will start to deliver meter data using its configured settings. By using the Elvaco OTC App, you can easily verify that the module is successfully communicating with the meter ("Meter communication") and is connected to the LoRaWAN network ("Network joined").

#### Read module status via meter display

In addition to the Elvaco OTC App, the current status of the module can be read via the meter display.

To retrieve the status of the module via the meter display, enter the tech loop and of the meter display and request the status information of the module. For more detailed information, please refer to the *Kamstrup MULTICAL Technical description*. Table 2 provides a description of how the current status of module is read off the meter's display.

As an example, if the display shows "5311111", that means that the module has been activated and is has successfully joined to the LoRaWAN network

Character, MSB -> lsb	Status
1-2	53 = Module identification number (CMi4140)
3	1 = All following characters are set to "1" 0 = One or more of the following characters are set to "0"
4	1 = Meter has granted active mode for the module 0 = Meter has requested the module to be idle
5	1 = Module has joined the LoRaWAN network 0 = module has not joined the LoRaWAN network
6	1 = Module SuperCap has been charged 0 = Module SuperCap is charging



Character, MSB -> LSB	Status
7	1 = Module is active 0 = Module is inactive

*Table 2: Module status indication on meter display*

## 6 Administration reference

### 6.1 Purpose

This chapter contains detailed information about configuring options and the different message formats of CMi4140.

### 6.2 Security and access control

CMi4140 has a configuration lock feature, which prevents unauthorized access to the module. When configuration lock has been enabled, a Product Access Key will be needed to access the device. For more information about security and access control for CMi4140, please refer to the One-touch commissioning (OTC) documentation, available on the Elvaco website.

### 6.3 Configuration options

CMi4140 is configured via the Elvaco OTC App which can be downloaded in Google Play. It uses NFC to transfer settings to the module. Downlink may also be used to for some applications, see section 6.8 Downlink for more information.



Please note that the Elvaco OTC app is only compatible with Android phones with Android 5.0 or later.

Table 3 provides a summary of all parameters and settings in CMi4140.

Field name (Abbr.)	Description	Default value	Device access Locked device & correct Product Access Key <b>or</b> Open device	Device access No Product Access Key	Downlink
Meter ID	Meter identification number of the meter. Not configurable.	N/A	Readable	Readable	N/A
Power mode	Used to activate/deactivate the module.	Passive	Readable / Writeable	Readable	N/A
Message format	The message format determines the structure and payload of the telegram sent from the module.	0x15 (Standard)	Readable / Writeable	Readable	Writeable
EcoMode	When activated, 11+1 years of battery-life is guaranteed by adapting the transmit interval of the module to current signal conditions.	On	Readable / Writeable	Readable	Writeable
Transmit interval	Sets the number of minutes between each transmission from the module.	60 min	Readable / Writeable	Readable	Writeable
Date & Time	Date and time set for the meter.	N/A	Readable	Readable	N/A

Field name (Abbr.)	Description	Default value	Device access Locked device & correct Product Access Key <b>or</b> Open device	Device access No Product Access Key	Downlink
Set absolute time	Sets the time of the meter.	N/A	Writeable	N/A	N/A
Set Time Relative	Adjusts the time of the meter relative to the current time.	N/A	N/A	N/A	Writeable
Set UTC offset	Sets the UTC offset of the meter.	N/A	Readable / Writeable	Readable	Writeable
Configuration Lock	Locks the module to prevent unauthorized access.	Open	Readable / Writeable	Readable	Writeable
<b>LoRaWAN settings</b>					
Device EUI	Unique module identification number. Not configurable.	Device-unique 64-bit number	Readable	Readable	N/A
Activation type	Sets the way the device joins the LoRaWAN network.	OTAA	Readable / Writeable	Readable	N/A
Network join	Displays whether the module has joined the LoRaWAN network or not.	N/A	Readable	Readable	N/A
Join EUI	Application ID that determines where data ends up.	0x 94 19 3A 03 0B 00 00 01	Readable / Writeable	Readable	N/A
Device address	32-bit address used by the module to identify itself on the LoRaWAN network.	N/A	Readable / Writeable	N/A	N/A
Current data rate	The current data rate used for the module.	N/A	Readable	Readable	N/A

Table 3: Configuration options

## 6.4 Time handling

The module relies on the meter's clock for keeping time. Time in the meter is assumed to be in standard local time (no DST). When synchronizing time in the meter using the OTC App, local standard time is always used, even if DST is in effect. The timestamped meter data sent from the module can be adjusted to be sent in UTC by specifying the "UTC offset" configuration parameter. The UTC offset will be subtracted from the timestamp prior to transmission. If the meter is in Sweden, which uses CET (Central European Time), it should have UTC offset set to +60 (+1h). In this case at time 12.00 a telegram is sent with timestamp 11.00 as this is the corresponding UTC time. A meter in New York (USA) should have a UTC offset of -300 (-5h) etc. A UTC offset of 0 means the meter time is used as-is.

If the meter is set to used DST this is ignored by the module and the standard time is used. Thus, the time on the meter's display may not match the time in the telegram or in the OTC App.

## 6.5 Adaptive data rate (ADR)

CMi4140 supports Adaptive Data Rate (ADR), part of the LoRaWAN standard, where the network server determines the optimal rate of communication for the module based on current signal conditions. In the best radio conditions, the module will use its highest data rate (DR5) in order to be as energy efficient as possible. When signal conditions are poor, the network server will incrementally lower the data rate until it is able to receive the message. When the data rate is low, the energy consumption per telegram will increase.

## 6.6 Transmit interval

The transmit interval is used to set how frequently the module should transmit data on the LoRaWAN network. The parameter can be set to a value between 5 and 1440 minutes (i.e. between 5-minute and daily values).

### 6.6.1 EcoMode

When EcoMode is active, it is able to achieve a battery-life of at least 11+1 years by utilizing a table of allowed transmit intervals settings for each data rate. When radio conditions are poor (and data rate is low), the module will be able to send data less frequently in order to conserve battery-life. When signal conditions are good, the module will be able to send data more frequently. When EcoMode is enabled, the module will continuously check if the set transmit interval is "allowed" by the EcoMode table. If a lower transmit interval is needed for the specific data rate in order to achieve 11 years of battery life, the module will adjust the parameter accordingly.

Table 4 shows the transmit intervals that the module will use for different data rates in order to achieve a 11-year battery-life.

Data rate	Transmit interval
DR0	180 min
DR1	120 min
DR2	60 min
DR3	30 min
DR4-DR5	15 min

Table 4: Transmit intervals for different data rates in EcoMode

Table 4 summarizes the transmit interval for different data rates **FW >= 1.03**.

Data rate	Transmit interval
DR0	360 min
DR1	240 min
DR2	120 min
DR3	60 min
DR4-DR5	30 min

Table 5: Data rate and transmit interval

\*Note that since Extended+ is scheduled the minimum practical limit is always 60 minutes.



If EcoMode has been disabled, guarantees about battery-life is no longer valid (even if EcoMode is activated later).

## 6.7 Message formats

CMi4140 has seven different message formats: *Standard*, *Compact*, *JSON*, *Scheduled – Daily redundant*, *Scheduled – Extended*, *Combined heat/cooling*, *Heat Intelligence* and *Scheduled extended +*. Each message format will be described in detail in this section.

## 6.7.1 Message structure

Message formats *Standard, Compact, Scheduled – Daily redundant, Scheduled – Extended, Combined heat/cooling, Heat Intelligence and Scheduled extended +.* are encoded on M-Bus format (date/time field are encoded on M-Bus format F). Message format JSON is encoded on JSON format.

All messages begin with one byte specifying the message format used.

All M-Bus encoded messages begin with one byte specifying the message format used. Then follows a sequence of data information blocks (DIBs), each one containing a data information field (DIF), a value information field (VIF) and a data field (DATA). The structure of the telegram is illustrated in Figure 1.




Figure 1: CMi4140 M-Bus message structure

For message format *JSON*, the data is presented as ASCII.

Field	Size	Description
Message format identifier	1 byte	0x15 = Standard 0x16 = Compact 0x17 = JSON 0x18 = Scheduled – Daily redundant 0x19 = Scheduled - Extended 0x1A = Combined heat/cooling 0x1B = Heat Intelligence 0x3B = Scheduled extended + telegram 1* 0x3C = Scheduled extended + telegram 2*  <ul style="list-style-type: none"> <li>• Only in FW&gt;=1.03</li> </ul>

Table 5: CMi4140 message formats

\*Scheduled - extended + telegram 2 cannot be selected as a telegram type. It is the ID of the second telegram when using message format Scheduled - extended +.

## 6.7.2 Structure and payload

In this section, a detailed description of the structure and payload for each message format is presented.

### Standard | 0x15

Figure 2 illustrates the structure of message format *Standard*. For a detailed description of the payload, see Table 6.




Figure 2: Structure, message format *Standard*

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0x15 (Standard)
1	Heat energy E1 / Cooling energy E3	6-7 bytes	INT32	Energy consumption (Wh, J, Cal) 0400xxxxxxxx = xxxxxxxx,xxx Wh 0401xxxxxxxx = xxxxxxxx,xx Wh 0402xxxxxxxx = xxxxxxxx,x Wh 0403xxxxxxxx = xxxxxxxx Wh 0404xxxxxxxx = xxxxxxxx * 10 Wh 0405xxxxxxxx = xxxxxxxx * 100 Wh 0406xxxxxxxx = xxxxxxxx kWh 0407xxxxxxxx = xxxxxxxx * 10 kWh 040Exxxxxxxxx = xxxxxxxx MJ 040Fxxxxxxxx = xxxxxxxx * 10 MJ 04FB0Dxxxxxxxx = xxxxxxxx MCal 04FB0Exxxxxxxxx = xxxxxxxx * 10 MCal 04FB0Fxxxxxxxx = xxxxxxxx * 100 MCal
2	Volume	6 bytes	INT32	Volume (m <sup>3</sup> ) 0411xxxxxxxx = xxxxxxxx * 0.00001 m <sup>3</sup> 0412xxxxxxxx = xxxxxxxx * 0.0001 m <sup>3</sup> 0413xxxxxxxx = xxxxxxxx * 0.001 m <sup>3</sup> 0414xxxxxxxx = xxxxxxxx * 0.01 m <sup>3</sup> 0415xxxxxxxx = xxxxxxxx * 0.1 m <sup>3</sup> 0416xxxxxxxx = xxxxxxxx m <sup>3</sup> 0417xxxxxxxx = xxxxxxxx * 10 m <sup>3</sup>
3	Power	4 bytes	INT16	Power (W) 022Bxxxx = xxxx W 022Cxxxx = xxxx * 10 W 022Dxxxx = xxxx * 100 W 022Exxxx = xxxx kW 022Fxxxx = xxxx * 10 kW
4	Flow	4 bytes	INT16	Flow (m <sup>3</sup> /h) 023Bxxxx = xxxx * 0.001 m <sup>3</sup> /h 023Cxxxx = xxxx * 0.01 m <sup>3</sup> /h 023Dxxxx = xxxx * 0.1 m <sup>3</sup> /h 023Exxxx = xxxx m <sup>3</sup> /h 023Fxxxx = xxxx * 10 m <sup>3</sup> /h

DIB	Field	Size	Data type	Description
5	Fw temp	4 bytes	INT16	Forward temperature (°C) 0258xxxx = xxxx * 0.001 °C 0259xxxx = xxxx * 0.01 °C 025Axxxx = xxxx * 0.1 °C 025Bxxxx = xxxx °C
6	Rt temp	4 bytes	INT16	Return temperature (°C) 025Cxxxx = xxxx * 0.001 °C 025Dxxxx = xxxx * 0.01 °C 025Exxxx = xxxx * 0.1 °C 025Fxxxx = xxxx °C
7	Meter ID	6 bytes	According to M-Bus EN13757-3 identification field	Meter ID 0C78xxxxxxxx
8	Info bits	7 bytes	INT32	Error and warning flags 04FD17xxxxxxxx  For further information about Info bits please refer to the meter's manual

Table 6: Payload, message format Standard

### Compact | 0x16

Figure 3 illustrates the structure for message format *Compact*. For a detailed description of the payload, see Table 7.




Figure 3: Structure, message format Compact

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0x16 (Compact)
1	Heat energy E1 / Cooling energy E3	6-7 bytes	INT32	Energy consumption (Wh, J, Cal) 0400xxxxxxxx = xxxxxxxx,xxx Wh 0401xxxxxxxx = xxxxxxxx,xx Wh 0402xxxxxxxx = xxxxxxxx,x Wh 0403xxxxxxxx = xxxxxxxx Wh 0404xxxxxxxx = xxxxxxxx * 10 Wh 0405xxxxxxxx = xxxxxxxx * 100 Wh 0406xxxxxxxx = xxxxxxxx kWh 0407xxxxxxxx = xxxxxxxx * 10 kWh 040Exxxxxxxx = xxxxxxxx MJ 040Fxxxxxxxx = xxxxxxxx * 10 MJ 04FB0Dxxxxxxxx = xxxxxxxx MCal 04FB0Exxxxxxxx = xxxxxxxx * 10 MCal 04FB0Fxxxxxxxx = xxxxxxxx * 100 MCal

DIB	Field	Size	Data type	Description
2	Meter ID	6 bytes	According to M-Bus EN13757-3 identification field	Meter ID 0C78xxxxxxxx
3	Info bits	7 bytes	INT32	Error and warning flags 04FD17xxxxxxxx  For further information about Info bits please refer to the meter's manual

Table 7: Payload, message format Compact

### JSON | 0x17

For message format *JSON*, the data is presented in a plain text format. Table 8 provides a description of all fields included in the telegram.

Field	Description
Message format identifier	0x17 (Message format <i>JSON</i> )
Energy	Energy consumption
Unit	Unit of energy consumption (Wh, kWh, MWh, GWh, J, kJ, MJ, GJ, Cal, kCal, MCal or GCal)
Meter ID	Identification number of the meter in which the module is mounted.

Table 8: Fields, message format JSON

An example of a telegram for message format *JSON* is presented below:

```
{"E":12345678,"U":"kWh","ID":87654321}
```

Figure 4: JSON message example

### Scheduled mode

For message formats of type "Scheduled" (Scheduled – Daily redundant and Scheduled – Extended), two types of messages will be transmitted from the module - a clock message and a data message. The difference between the two is described in Table 9. A detailed description of the payload of the clock message is provided in Table 10.

Message	Time interval	Description
Clock message	Once per day	The clock message presents the current time of the meter. It can be used to verify that the clock is correct and has not drifted more than accepted.
Data message	Determined by transmit interval parameter.	The actual meter data collected from the meter. For more information, see Table 12 and Table 13.

Table 9: Clock message and data message

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0xFA (=Clock message)
1	Date/time	6 bytes	32 bit binary integer M-Bus type F	046Dxxxxxx = Valid date/time message 346Dxxxxxx = Invalid date/time message

Table 10: Payload, clock message



The clock message will be transmitted once every day and the data message at least (regulated by transmit interval parameter or EcoMode) once every day. The transmit interval can only be set the values listed in Table 11.

Note that although the meter readout will occur on top-of-the-hour, the data message will not necessarily be transmitted at that exact time. The LoRa transmission will occur after a random delay of 0-15 minutes to decrease the risk of collisions. The readout for the clock message occurs at a random hour (00:00-23:00) at a random minute in the 35-45 interval and will be transmitted immediately after readout.

When using message format *Scheduled*, the transmit interval cannot not be set to higher than 1440 minutes.

Parameter	Values	Unit
Transmit interval	60, 120, 180, 240, 360, 480, 720, 1440	Minutes

Table 11: Transmit interval options for Scheduled message formats

### Scheduled - daily redundant | 0x18

The data message of *Scheduled mode-daily redundant* contains an accumulated daily energy field, which is updated at 24:00 each day. In other words, depending on transmit interval settings and data rate, the field will be included in between 1-24 telegrams per day. This will increase the probability of the value being received. For example, if the transmit interval is set to “2”, the accumulated energy read at 24:00 will be transmitted 12 times during the 24 next coming hours (every 2<sup>nd</sup> hour).




Figure 5: Structure, message format Scheduled – daily redundant

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0x18 (Scheduled-daily redundant)
1	Heat energy E1 / Cooling Energy E3	6-7 bytes	INT32	Energy consumption (Wh, J, Cal) 0400xxxxxxxx = xxxxxxxx,xxx Wh 0401xxxxxxxx = xxxxxxxx,xx Wh 0402xxxxxxxx = xxxxxxxx,x Wh 0403xxxxxxxx = xxxxxxxx Wh 0404xxxxxxxx = xxxxxxxx * 10 Wh 0405xxxxxxxx = xxxxxxxx * 100 Wh 0406xxxxxxxx = xxxxxxxx kWh 0407xxxxxxxx = xxxxxxxx * 10 kWh 040Exxxxxxxx = xxxxxxxx MJ 040Fxxxxxxxx = xxxxxxxx * 10 MJ 04FB0Dxxxxxxxx = xxxxxxxx MCal 04FB0Exxxxxxxx = xxxxxxxx * 10 MCal 04FB0Fxxxxxxxx = xxxxxxxx * 100 MCal

DIB	Field	Size	Data type	Description
2	Volume	6 bytes	INT32	Volume (m <sup>3</sup> )  0411xxxxxxxx = xxxxxxxx * 0.00001 m <sup>3</sup> 0412xxxxxxxx = xxxxxxxx * 0.0001 m <sup>3</sup> 0413xxxxxxxx = xxxxxxxx * 0.001 m <sup>3</sup> 0414xxxxxxxx = xxxxxxxx * 0.01 m <sup>3</sup> 0415xxxxxxxx = xxxxxxxx * 0.1 m <sup>3</sup> 0416xxxxxxxx = xxxxxxxx m <sup>3</sup> 0417xxxxxxxx = xxxxxxxx * 10 m <sup>3</sup>
3	Meter ID	6 bytes	According to M-Bus EN13757-3 identification field	Meter ID  0C78xxxxxxxx
4	Info bits	7 bytes	INT32	Error and warning flags  04FD17xxxxxxxx  For further information about Info bits please refer to the meter's manual
5	Meter date/time	6 bytes	INT32	Meter date and time (YY-MM-DD HH:MM)  046Dxxxxxxxx  Bit 31-28 = Year-high* Bit 27-24 = Month Bit 23-21 = Year-low* Bit 20-16 = Day Bit 15 = Summertime flag** Bit 12-8 = Hour Bit 7 = Error flag*** Bit 6 = Reserved for future use*** Bit 5-0 = Minute  *The year is read by combining the year-high and year-low field. For example, year-high = 0010 and year-low = 010 => year = 0010010  **0 = standard time, 1= daylight-saving time  ***0 = timestamp is valid, 1 = timestamp is <b>not</b> valid
6	Accumulated heat / cooling energy at 24:00	6-7 Bytes	INT32	Energy consumption (Wh, J, Cal)  4400xxxxxxxx = xxxxxxxx,xxx Wh 4401xxxxxxxx = xxxxxxxx,xx Wh 4402xxxxxxxx = xxxxxxxx,x Wh 4403xxxxxxxx = xxxxxxxx Wh 4404xxxxxxxx = xxxxxxxx *10 Wh 4405xxxxxxxx = xxxxxxxx *100 Wh 4406xxxxxxxx = xxxxxxxx kWh 4407xxxxxxxx = xxxxxxxx * 10 kWh 440Exxxxxxxxx = xxxxxxxx MJ 440Fxxxxxxxx = xxxxxxxx * 10 MJ 44FB0Dxxxxxxxx = xxxxxxxx MCal 44FB0Exxxxxxxxx = xxxxxxxx * 10 MCal 44FB0Fxxxxxxxx = xxxxxxxx * 100 MCal

DIB	Field	Size	Data type	Description
				Note: Before a midnight reading has been performed the Function field of the DIF is set to "value during error state" to indicate that the value is not valid.

Table 12: Payload, message format Scheduled – daily redundant

### Scheduled - Extended | 0x19

The data message of *Scheduled mode-Extended* contains all the data fields from message format *Standard*. In addition to these, it also includes the meter date/time to transmit messages on the full hour. As for all *Scheduled* message formats, the transmit interval can only be set to the values included in Table 11.

A detailed description of the payload in the message format is presented in Table 13.

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0x19 (Scheduled-Extended)
1	Heat energy E1 / Cooling Energy E3	6-7 bytes	INT32	Energy consumption (Wh, J, Cal) 0400xxxxxxxx = xxxxxxxx,xxx Wh 0401xxxxxxxx = xxxxxxxx,xx Wh 0402xxxxxxxx = xxxxxxxx,x Wh 0403xxxxxxxx = xxxxxxxx Wh 0404xxxxxxxx = xxxxxxxx * 10 Wh 0405xxxxxxxx = xxxxxxxx * 100 Wh 0406xxxxxxxx = xxxxxxxx kWh 0407xxxxxxxx = xxxxxxxx * 10 kWh 040Exxxxxxxxx = xxxxxxxx MJ 040Fxxxxxxxx = xxxxxxxx * 10 MJ 04FB0Dxxxxxxxx = xxxxxxxx MCal 04FB0Exxxxxxxxx = xxxxxxxx * 10 MCal 04FB0Fxxxxxxxx = xxxxxxxx * 100 MCal
2	Volume	6 bytes	INT32	Volume (m <sup>3</sup> ) 0411xxxxxxxx = xxxxxxxx * 0.00001 m <sup>3</sup> 0412xxxxxxxx = xxxxxxxx * 0.0001 m <sup>3</sup> 0413xxxxxxxx = xxxxxxxx * 0.001 m <sup>3</sup> 0414xxxxxxxx = xxxxxxxx * 0.01 m <sup>3</sup> 0415xxxxxxxx = xxxxxxxx * 0.1 m <sup>3</sup> 0416xxxxxxxx = xxxxxxxx m <sup>3</sup> 0417xxxxxxxx = xxxxxxxx * 10 m <sup>3</sup>
3	Power / Flow / Fw temp / Rt temp	12 bytes	INT64	Byte 0-2 = DIF/VIF codes, 0x07FFA0 Byte 3 = VIFE defining scaling of Power/Flow -Bit 6.4 (n), 10 <sup>n-3</sup> W, n = 0..7 -Bit 2..0 (m), 10 <sup>m-3</sup> m <sup>3</sup> /h, m = 0..7 Byte 4-5 = Fw temp (lsByte -> msByte), °C, 2 decimals Byte 6-7 = Rt temp (lsByte -> msByte), °C, 2 decimals Byte 8-9 = Flow (lsByte -> msByte), 10 <sup>m-6</sup> m <sup>3</sup> /h Byte 10-11 = Power (lsByte -> msByte), 10 <sup>n-3</sup> W

DIB	Field	Size	Data type	Description
4	Meter ID / Info bits	11 bytes	INT96	Byte 0-2 = DIF/VIF codes, 0x07FF21 Byte 3-6 = Info bits (lsByte -> msByte) Byte 7-10 = Meter ID (lsByte -> msByte)*  *Sent in binary format
5	Meter date/time	6 bytes	INT32	Meter date and time (YY-MM-DD HH:MM)  046Dxxxxxxxx  Bit 31-28 = Year-high* Bit 27-24 = Month Bit 23-21 = Year-low* Bit 20-16 = Day Bit 15 = Summertime flag** Bit 12-8 = Hour Bit 7 = Error flag*** Bit 6 = Reserved for future use*** Bit 5-0 = Minute  *The year is read by combining the year-high and year-low field. For example, year-high = 0010 and year-low = 010 => year = 0010010  **0 = standard time, 1= daylight-saving time  ***0 = timestamp is valid, 1 = timestamp is <b>not</b> valid

Table 13: Payload, message format Scheduled - Extended

### Combined heat/cooling | 0x1A

Message format *Combined heat/cooling* is made to be used in meters that measures both heating and cooling energy. Table 14 describes the telegram of the meter.



Message format *Combined heat/cooling* is only meant to be used in combined heat/cooling meters.

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0x1A (Combined heat/cooling)
1	Heat energy E1	6-7 bytes	INT32	Energy consumption (Wh, J, Cal)  0400xxxxxxxx = xxxxxxxx,xxx Wh 0401xxxxxxxx = xxxxxxxx,xx Wh 0402xxxxxxxx = xxxxxxxx,x Wh 0403xxxxxxxx = xxxxxxxx Wh 0404xxxxxxxx = xxxxxxxx * 10 Wh 0405xxxxxxxx = xxxxxxxx * 100 Wh 0406xxxxxxxx = xxxxxxxx kWh 0407xxxxxxxx = xxxxxxxx * 10 kWh 040Exxxxxxxxx = xxxxxxxx MJ 040Fxxxxxxxx = xxxxxxxx * 10 MJ 04FB0Dxxxxxxxx = xxxxxxxx MCal 04FB0Exxxxxxxxx = xxxxxxxx * 10 MCal 04FB0Fxxxxxxxx = xxxxxxxx * 100 MCal

DIB	Field	Size	Data type	Description
2	Cooling Energy E3	8-9 bytes	INT32	Energy consumption (Wh, J, Cal)  0483FF02xxxxxxxx = xxxxxxxx Wh 0484FF02xxxxxxxx = xxxxxxxx * 10 Wh 0485FF02xxxxxxxx = xxxxxxxx * 100 Wh 0486FF02xxxxxxxx = xxxxxxxx kWh 0487FF02xxxxxxxx = xxxxxxxx * 10 kWh 048EFF02xxxxxxxx = xxxxxxxx MJ 048FFF02xxxxxxxx = xxxxxxxx * 10 MJ 04FB8DFF02xxxxxxxx = xxxxxxxx MCal 04FB8EFF02xxxxxxxx = xxxxxxxx * 10 MCal 04FB8FFF02xxxxxxxx = xxxxxxxx * 100 MCal
3	Volume	6 bytes	INT32	Volume (m <sup>3</sup> )  0411xxxxxxxx = xxxxxxxx * 0.00001 m <sup>3</sup> 0412xxxxxxxx = xxxxxxxx * 0.0001 m <sup>3</sup> 0413xxxxxxxx = xxxxxxxx * 0.001 m <sup>3</sup> 0414xxxxxxxx = xxxxxxxx * 0.01 m <sup>3</sup> 0415xxxxxxxx = xxxxxxxx * 0.1 m <sup>3</sup> 0416xxxxxxxx = xxxxxxxx m <sup>3</sup> 0417xxxxxxxx = xxxxxxxx * 10 m <sup>3</sup>
4	Fw temp	4 bytes	INT16	Forward temperature (°C)  0258xxxx = xxxx * 0.001 °C 0259xxxx = xxxx * 0.01 °C 025Axxxx = xxxx * 0.1 °C 025Bxxxx = xxxx °C
5	Rt temp	4 bytes	INT16	Return temperature (°C)  025Cxxxx = xxxx * 0.001 °C 025Dxxxx = xxxx * 0.01 °C 025Exxxx = xxxx * 0.1 °C 025Fxxxx = xxxx °C
6	Meter ID	6 bytes	According to M-Bus EN13757-3 identification field	Meter ID  0C78xxxxxxxx
7	Info bits	7 bytes	Uint32	Error and warning flags  04FD17xxxxxxxx  For further information about Info bits please refer to the meter's manual

Table 14: Payload, message format Combined heat/cooling

### Heat intelligence | 0x1B

This telegram will be adapted to the type of meter in which the module is mounted. That means that it will look slightly different depending on whether the module is mounted in a heat meter, a cooling meter or a combined heat/cooling meter.

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0x1B (Heat intelligence)
1	Heat energy E1	6-7 bytes	INT32	Energy consumption (Wh, J, Cal)  0400xxxxxxxx = xxxxxxxx,xxx Wh 0401xxxxxxxx = xxxxxxxx,xx Wh 0402xxxxxxxx = xxxxxxxx,x Wh 0403xxxxxxxx = xxxxxxxx Wh 0404xxxxxxxx = xxxxxxxx * 10 Wh 0405xxxxxxxx = xxxxxxxx * 100 Wh 0406xxxxxxxx = xxxxxxxx kWh 0407xxxxxxxx = xxxxxxxx * 10 kWh 040Exxxxxxxxx = xxxxxxxx MJ 040Fxxxxxxxx = xxxxxxxx * 10 MJ 04FB0Dxxxxxxxx = xxxxxxxx MCal 04FB0Exxxxxxxxx = xxxxxxxx * 10 MCal 04FB0Fxxxxxxxx = xxxxxxxx * 100 MCal
2*	Cooling energy E3	8-9 bytes	INT32	Energy consumption (Wh, J, Cal)  0480 FF02xxxxxxxx = xxxxxxxx,xxx Wh 0481 FF02xxxxxxxx = xxxxxxxx,xx Wh 0482 FF02xxxxxxxx = xxxxxxxx,x Wh 0483FF02xxxxxxxx = xxxxxxxx Wh 0484FF02xxxxxxxx = xxxxxxxx * 10 Wh 0485FF02xxxxxxxx = xxxxxxxx * 100 Wh 0486FF02xxxxxxxx = xxxxxxxx kWh 0487FF02xxxxxxxx = xxxxxxxx * 10 kWh 048EFF02xxxxxxxx = xxxxxxxx MJ 048FFF02xxxxxxxx = xxxxxxxx * 10 MJ 04FB8DFF02xxxxxxxx = xxxxxxxx MCal 04FB8EFF02xxxxxxxx = xxxxxxxx * 10 MCal 04FB8FFF02xxxxxxxx = xxxxxxxx * 100 MCal
3	Volume	6 bytes	INT32	Volume (m <sup>3</sup> )  0411xxxxxxxx = xxxxxxxx * 0.00001 m <sup>3</sup> 0412xxxxxxxx = xxxxxxxx * 0.0001 m <sup>3</sup> 0413xxxxxxxx = xxxxxxxx * 0.001 m <sup>3</sup> 0414xxxxxxxx = xxxxxxxx * 0.01 m <sup>3</sup> 0415xxxxxxxx = xxxxxxxx * 0.1 m <sup>3</sup> 0416xxxxxxxx = xxxxxxxx m <sup>3</sup> 0417xxxxxxxx = xxxxxxxx * 10 m <sup>3</sup>
4	Meter ID / Info bits	16 bytes	INT96	Byte 0-2 = DIF/VIF codes, 0x07FF21 Byte 3-6 = Info bits (lsByte -> msByte) Byte 7-10 = Meter ID (lsByte -> msByte)*  *Sent in binary format
5	Energy E8	7 bytes	INT32	Energy (m <sup>3</sup> * °C)  04FF07xxxxxxxx = xxxxxxxx m <sup>3</sup> * °C

DIB	Field	Size	Data type	Description
6	Energy E9	7 bytes	INT32	Energy (m <sup>3</sup> * °C)  04FF08xxxxxxxx = xxxxxxxx m <sup>3</sup> * °C

Table 15: Payload, message format Heat Intelligence

### Scheduled – Extended + | 0x3B/0x3C

The data message of message format *Scheduled mode-extended +* contains three tariffs and all the meter data included in the *Standard* telegram. In addition to these, a timestamp from the meter (meter date/time) is included in each telegram. It also is divided into two telegrams for keeping each telegram below 45 bytes.

#### Telegram 1

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0x3B (Scheduled-Extended +, telegram 1)
1	Heat energy E1 / Cooling energy E3	6-7 bytes	INT32	Energy consumption (Wh, J, Cal)  0400xxxxxxxx = xxxxxxxx,xxx Wh 0401xxxxxxxx = xxxxxxxx,xx Wh 0402xxxxxxxx = xxxxxxxx,x Wh 0403xxxxxxxx = xxxxxxxx Wh 0404xxxxxxxx = xxxxxxxx * 10 Wh 0405xxxxxxxx = xxxxxxxx * 100 Wh 0406xxxxxxxx = xxxxxxxx kWh 0407xxxxxxxx = xxxxxxxx * 10 kWh 040Exxxxxxxxx = xxxxxxxx MJ 040Fxxxxxxxx = xxxxxxxx * 10 MJ 04FB0Dxxxxxxxx = xxxxxxxx MCal 04FB0Exxxxxxxxx = xxxxxxxx * 10 MCal 04FB0Fxxxxxxxx = xxxxxxxx * 100 MCal
2	Energy Tariff 2	8	INT32	840203xxxxxxxx = xxxxxxxx Wh
3	Energy Tariff 3	8	INT32	840303xxxxxxxx = xxxxxxxx Wh
4	Meter ID	6 bytes	According to M-Bus EN13757-3 identification field	Meter ID  0C78xxxxxxxx

DIB	Field	Size	Data type	Description
6	Meter date/time	6 bytes	INT32	Meter date and time (YY-MM-DD HH:MM) 046Dxxxxxxxx Bit 31-28 = Year-high* Bit 27-24 = Month Bit 23-21 = Year-low* Bit 20-16 = Day Bit 15 = Summertime flag** Bit 12-8 = Hour Bit 7 = Error flag*** Bit 6 = Reserved for future use*** Bit 5-0 = Minute  *The year is read by combining the year-high and year-low field. For example, year-high = 0010 and year-low = 010 => year = 0010010  **0 = standard time, 1= daylight-saving time  ***0 = timestamp is valid, 1 = timestamp is <b>not</b> valid

Table 16: Payload, message format Scheduled – Extended +

## Telegram 2

DIB	Field	Size	Data type	Description
0	Message format identifier	1 byte	-	0x3C (Scheduled-Extended +)
1	Volume	6 bytes	INT32	Volume (m <sup>3</sup> ) 0411xxxxxxxx = xxxxxxxx * 0.00001 m <sup>3</sup> 0412xxxxxxxx = xxxxxxxx * 0.0001 m <sup>3</sup> 0413xxxxxxxx = xxxxxxxx * 0.001 m <sup>3</sup> 0414xxxxxxxx = xxxxxxxx * 0.01 m <sup>3</sup> 0415xxxxxxxx = xxxxxxxx * 0.1 m <sup>3</sup> 0416xxxxxxxx = xxxxxxxx m <sup>3</sup> 0417xxxxxxxx = xxxxxxxx * 10 m <sup>3</sup>
2	Power	4 bytes	INT16	Power (W) 022Bxxxx = xxxx W 022Cxxxx = xxxx * 10 W 022Dxxxx = xxxx * 100 W 022Exxxx = xxxx kW 022Fxxxx = xxxx * 10 kW
3	Flow	4 bytes	INT16	Flow (m <sup>3</sup> /h) 023Bxxxx = xxxx * 0.001 m <sup>3</sup> /h 023Cxxxx = xxxx * 0.01 m <sup>3</sup> /h 023Dxxxx = xxxx * 0.1 m <sup>3</sup> /h 023Exxxx = xxxx m <sup>3</sup> /h 023Fxxxx = xxxx * 10 m <sup>3</sup> /h



DIB	Field	Size	Data type	Description
4	Fw temp	4 bytes	INT16	Forward temperature (°C)  0258xxxx = xxxx * 0.001 °C 0259xxxx = xxxx * 0.01 °C 025Axxxx = xxxx * 0.1 °C 025Bxxxx = xxxx °C
5	Rt temp	4 bytes	INT16	Return temperature (°C)  025Cxxxx = xxxx * 0.001 °C 025Dxxxx = xxxx * 0.01 °C 025Exxxx = xxxx * 0.1 °C 025Fxxxx = xxxx °C
6	Meter ID	6 bytes	According to M-Bus EN13757-3 identification field	Meter ID  0C78xxxxxxxx
7	Meter date/time	6 bytes	INT32	Meter date and time (YY-MM-DD HH:MM)  046Dxxxxxxxx  Bit 31-28 = Year-high* Bit 27-24 = Month Bit 23-21 = Year-low* Bit 20-16 = Day Bit 15 = Summertime flag** Bit 12-8 = Hour Bit 7 = Error flag*** Bit 6 = Reserved for future use*** Bit 5-0 = Minute  *The year is read by combining the year-high and year-low field. For example, year-high = 0010 and year-low = 010 => year = 0010010  **0 = standard time, 1 = daylight-saving time  ***0 = timestamp is valid, 1 = timestamp is <b>not</b> valid
8	Info bits	7 bytes	INT32	Error and warning flags  04FD17xxxxxxxx  For further information about Info bits please refer to the meter's manual

Table 17: Payload, message format Scheduled – Extended +

**\*Note!** This DIB is only included in combined heat/cooling meters, i.e. not in pure heat meters or pure cooling meters.

### 6.7.3 Meter communication error message

The payloads using M-Bus encoded data uses the Function field of the DIF to indicate errors. In this case it is set to “value during error state” (M-Bus standard EN 13757-3:2013) and the value sent should not be used. A typical case for this is when the module is unable to communicate with the meter and retrieve meter values, in which case all the fields in the payload have the DIF indicating “value during error state”.

In case of erroneous data or if the module is unable to communicate with meter, bit 4-5 of the bit of the DIF code (first byte of each index field) will be set to 11b. For example, a DIF code of 0x02 will be set to 0x32 in case of error. (This applies to all message format except JSON.) For message format JSON, the actual value will be replaced with "null" in case of error state. If no meter communication is possible at all, all fields have this error indication set.

## 6.8 Downlink

CMi4140 supports configuration via downlink, i.e. sending commands to an end-device via the LoRaWAN network. **Note that this feature should only be used sparingly due to bandwidth consideration.** Communication via downlink is sent on port 2 and can only be made in a short window after an uplink transmission from module to server. Therefore, time-critical communication should not be performed over downlink.

Downlink commands are structured according to the following format: "0x00" "TLV" "Number of bytes in configuration" "Configuration". For a complete description of all available downlink commands, see Table 18.

Field name	TLV	Number of bytes in configuration	Configuration	Example
Configuration lock	0x05	0x01	0x00 = Locked 0x01 = Open	0x00050101 (Enables configuration lock)
Transmit interval	0x06	0x02	0xNumber of minutes between transmission (lsByte -> msByte)	0x0006021E00 (Sets the Tx interval to 30 minutes)
Message format	0x07	0x01	0x15 = Message format <i>Standard</i> 0x16 = Message format <i>Compact</i> 0x17 = Message format <i>JSON</i> 0x18 = Message format <i>Scheduled-daily redundant</i> 0x19 = Message format <i>Scheduled-Extended</i> 0x1A = Message format <i>Combined heat/cooling</i> 0x1B = Message format <i>Heat Intelligence</i>	0x00070116 (Sets the message format to compact)
EcoMode	0x0F	0x01	0x00 = Disable EcoMode 0x01 = Enable EcoMode	0x000F0100 (Disables EcoMode)
Set Time Relative	0x13	0x04	0xNumber of seconds* (lsByte -> msByte)  *Negative numbers supported.	0x0013043C000000 (Adds 60 seconds to the current time)  0x0013043C000080 (Subtracts 60 seconds from the current time)
UTC offset	0x17	0x02	0xNumber of minutes* (lsByte -> msByte)	0x17023C00 (Sets the UTC offset to +60 minutes)

Field name	TLV	Number of bytes in configuration	Configuration	Example
			*Negative numbers supported.	0x17023C80 (Sets the UTC offset to -60 minutes)
Reboot	0x22	0x02	0x759E is used to reboot device (note endianness, LSB first).	0x0022029E75 (Reboots the device)

Table 18: Downlink commands

## 7 Technical specifications

Type	Value	Unit	Comments
<b>Mechanics</b>			
Dimensions (w x h x d)	90 x 12 x 35	mm	
Weight	33	g	
Mounting	In module slot of Kamstrup MULTICAL® 403/603/803	-	
External antenna connector	MCX		
<b>Electrical connections</b>			
Supply voltage	Internal meter battery	-	
<b>Electrical characteristics</b>			
Nominal voltage	3.0	VDC	
Power consumption (max)	50	mA	
Power consumption (sleep mode)	2.5	µA	
<b>Environmental specifications</b>			
Operating temperature	+5 to +55	°C	
Operating humidity	0 - 93	% RH	No condensation
Operating altitude	2000	m	
Pollution degree	Degree 1	-	
Usage environment	Indoors	-	
Storage temperature	-20 to +60	°C	
<b>Radio characteristics</b>			
Frequency	868	MHz	
Output power	14	dBm	
Receiver sensitivity	-135	dBm	
<b>LoRaWAN characteristics</b>			
Device class	Class A	-	Bi-directional
LoRa version	1.0.2	-	
Activation	OTAA or ABP	-	
Data rate	DR0 - DR5	-	250 – 5470 bit/s
<b>User interface</b>			
Configuration	NFC via Elvaco OTC app or downlink data	-	

## 8 Type approvals

CMi4140 is designed to comply with the directives and standards listed below.

Approval	Description
EMC	EN 301 489-1, EN 309 489-3
LoRa Alliance®	LoRaWAN® Certified

## 9 Document history

### 9.1 Versions

Version	Date	Description
V0.1	2019-03	PoC version
V0.2	2019-10	Evaluation samples version
V1.0	2019-12	Commercial release version
V1.1	2020-06	Commercial release v1.1
V1.2	2021-05	Commercial release v1.2
V1.3	2021-11	Commercial release v1.3

## 10 References

### 10.1 Terms and abbreviations

Abbreviation	Description
DIB	Data Information Block
DIF	Data Information Field
VIF	Value Information Field
MCM	Meter Connectivity Module

### 10.2 Number representation

- Decimal numbers are represented as normal number, i.e. 10 (ten).
- Hexadecimal numbers are represented with prefix 0x, i.e. 0x0A (ten)
- Binary numbers are represented with prefix 0b, i.e. 0b00001010 (ten)
- Payload data follows the M-Bus Standard with the least significant byte (LSB) first

### 10.3 European Standards

- M-Bus standard EN 13757-3:2013 Communication systems for and remote reading of meters – Part 3: Dedicated application layer